



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

KIA

MOD.

SPORTAGE

YEAR.

00 →

PETROL
DIESEL

ALARM/SIREN POSITION

Position the compact alarms and the sirens in the engine compartment on the side of the servobrake.

CENTRAL UNIT POSITION

Position the modular systems and the modules under the left of the dashboard, driver's side. Pass the cables using the free core hitch located on the side of the servobrake, under the accelerator cable.

POWER SUPPLY

+ **30**: connect to the big wire that drives the fuse box.
- **31**: connect with a cable terminal directly to the car body.

IGNITION WIRE

+ **15/54**: connect to the 1 mm² BLACK/WHITE wire located in the wiring harness coming out of the ignition key.

DIRECTION INDICATORS

Connect to the RED/ BLUE wire with BLACK references and RED/WHITE wire with BLACK references located in the 8 way black connector, behind the bracket, on the left of the steering column.

ELECTRIC WINDOWS

Front window, driver's side:

cut the RED/BLUE wire.

Front window, passenger's side:

cut the RED/BLUE wire.

Connections must be done in the 11 way transparent connector coming out of the push buttons inside the driver's side door.

Rear window, driver's side:

cut the RED wire.

Rear window, passenger's side:

cut the LIGHT BLUE/WHITE wire.

Connections for the rear windows must be done in the wiring harness coming out of the driver's side door.

CENTRAL DOORS LOCKING

Negative control signal

Connect to the BROWN/BLACK wire (unlock) and BLUE/BLACK wire (lock) located in the wiring harness coming out of the 17 way yellow connector, on the left of the steering column.

IMMOBILISATION POINT

Cut the GREEN wire located in the wiring harness coming out of the relay marked FUEL PUMP located in the fuse box in the engine compartment.

STARTER

+ **50**: Cut the BLACK /YELLOW wire located in the wiring harness coming out of the ignition key.

BONNET SWITCH

Install an additional switch on the front headlamp support plate.

DOORS SWITCH

Connect to the YELLOW/GREEN wire located in the wiring harness coming out of the 21 way transparent connector, connected to the central doors locking unit placed above the gloves box, passenger's side.

BOOT SWITCH

Connect to the GREEN/YELLOW wire located in the wiring harness coming out of the boot lamp.